

## **Managing the Design and Construction of Grouted Cut-Offs in Emergency Conditions**

Dr. Donald A. Bruce, Member, Geo-Institute<sup>1</sup>

### **Abstract**

Structures such as dams and quarries create differential piezometric heads in their vicinity when operational. In certain geological conditions, such heads may, in association with other factors, create sudden water flows — under or around a dam, into a deep quarry. Grouting is often proposed as an emergency solution to such events which can be of catastrophic significance, in many ways. This paper provides a nine-step guide to managing the design and construction of the grouting involved in such emergency situations.

### **1. Introduction**

Although it is conventional wisdom to state that dams in the U.S. were invariably built on “good” sites, since the country was so large, and engineers always had the “walk away” solution of relocating the structure elsewhere, this view can be quickly discredited. A significant percentage of the United States’ large dams – identified in a 2002 study by *Hydropower and Dams* as being 6724 in number, were – had to be – founded on sites with less than perfect geology. The magnificent vision of the Tennessee Valley Authority could not have been realized if an embargo had been placed on sites with limestone bedrock. Construction of the great U.S. Army Corps of Engineers’ and private utility structures of later decades in Indiana, Tennessee, Missouri, Georgia, and Alabama in particular would also have been denied if fears over karstic response had overridden the contemporary social and economic needs of the community.

In addition, there are cases where the bedrock is found to contain other soluble rock types. Whereas it is typical practice to install a grout curtain under a new dam, such an operation cannot be guaranteed to comprehensively treat a karstic rock mass

---

<sup>1</sup> President, Geosystems, L.P., P.O. Box 237, Venetia, PA 15367, U.S.A., Phone: (724) 942-0570, Fax: (724) 942-1911, dabruce@geosystemsbruce.com.

to a degree that seepage under long-term service conditions may not – eventually – result in channels being opened through features in the karst filled with residual clay or other erodable or weathered materials. This long-term deterioration may be superimposed on any short-term disturbance to the karstic terrain created by construction activities, such as blasting, excavation, and the local alteration of piezometric levels. Grout curtains in virgin karst have a finite effective life – the length of which depends on the rock mass characteristics, the intensity and quality of any grouting conducted, and the prevailing hydraulic gradients. Unfortunately, this life expectancy cannot be reliably or precisely predicted, and the final deterioration can come very quickly. Massive sudden inflow through karstic features under an existing dam could well create a dam safety situation (if the overlying or adjacent structures were adversely affected) or could cause severe financial consequence if lake levels could not be maintained. In this case, power generation, flood regulation, and/or recreational impacts would be felt and, of course, there could well be real potential for catastrophic human and property losses downstream.

The problem of providing long-term security to dams on karst has been assiduously addressed by many Federal and private owners for over 80 years. In particular, in recent years, major rehabilitations have been funded for a number of large and vital existing structures owned by the U.S. Army Corps of Engineers, including Beaver Dam, AR; Walter F. George Dam, GA; and Mississenewa Dam, IN (Bruce et al., 2006). All have been protected by constructing “positive” concrete cut off walls – overlapping large diameter piles in the case of Beaver Dam (Bruce and Dugnani, 1996), diaphragm walls in the latter instances. A notable exception to this pattern has been the repair of the foundations of Patoka Lake Dam, IN, where a relatively innovative grout curtain (Dreese et al., 2003) was selected on overwhelming cost reasons over a concrete wall. Similarly, the recent karst-related seepage problem of a major TVA structure was also resolved by the use of contemporary grouting principles (Bruce et al., 1998). Large scale remediations of Clearwater Dam, MO and Wolf Creek Dam, KY are currently underway involving grouting solutions to facilitate concrete cut-off wall construction.

Similar challenges are found in the limestone/dolomite quarrying industry where it is not unusual to find well-developed pits reaching several hundred feet below the regional ground level (Lolcama et al., 1999). Many such quarries remain relatively “dry” i.e., the typical inflow due to groundwater seepage is less than 1,000 gpm. However, there are examples where, due to a combination of geological, hydrological topographical, climatic and man-induced factors, relatively massive and sudden inflows may develop. Such events are potentially catastrophic for the quarry owners since vital equipment and mineral reserves can become quickly submerged, and the cost of pumping out inflows of 40,000 gpm or more (Bruce et al., 2001) is invariably and unacceptably high. Depending on the local conditions, such events may also trigger sinkhole developments and/or cause significant variations in the piezometric levels outside the quarry. Sinkholes have the potential to severely disrupt overlying transportation facilities and residential, educational and commercial developments. Sinkholes can lead to loss of human life.

This paper relates to the “sudden flow” phenomenon as described above for dams and quarries. Such events are typically highly stressful and emotional for all

parties, especially given the potential consequences of “failure.” They invariably present a technical scenario which is extremely challenging to resolve. It is at this time that logic often is lost in the rush, and the “fire, aim, ready” syndrome kicks in. The paper presents a rational approach to responding to, and resolving, emergency situations in which grouting is to be employed.

## **2. The Fundamental Elements of emergency response Management**

The following 9-step sequence is consistent with the three fundamental stages in the implementation of any successful remedial grouting operation:

- Exploration and situation assessment.
- Responsive execution.
- Verification and monitoring of performance.

Sudden, significant and obvious changes to the preexisting structural and hydrological regimes characterize a karst-related flow event. Flow or seepage rates may increase substantially – by an order of magnitude or more — the flow may be discolored, new seepage entry and exit points may develop (e.g., “eddies” and “boils”), piezometric surfaces may drop, and/or surface manifestations may occur in the form of depressions in embankments or sinkholes in overlying overburden.

At such times, normal facility operations are interrupted or suspended, and depending on the severity of the situation, a fundamental structural safety issue may be declared and a wide range of technical, operational, managerial, financial, and regulatory bodies may become involved. Time will be of the essence in order that resolution is achieved as quickly and cost effectively as possible, and that any safety-related issue is correctly and firmly managed. The following steps reflect the approach the author has developed over the course of several such events, where flows of the order of 40,000 gpm at differential heads of up to 300 feet have suddenly developed and grouting has been proposed as the remedial process, at least for the short term.

Step 1. Appoint a Project Manager to act as a coordinator of the short-term emergency and the subsequent longer-term remediation efforts. This Manager should be drawn from the ranks of the facility owner, and should have long and direct experience with the construction and operation of the site and with the modus operandi of the ownership. The Manager should be divorced from his prior routine duties as far as possible, and should be fully empowered to seek further assistance, both from internal resources and external consultants. He must have the authority to act independently and the skills to exert effective leadership. A separate “mission control” room should be established for his use, wherein all data are collected and analyzed and all technical and planning meetings are held. Every meeting should be formally documented to form the basis for “post action” reports.

- Step 2. Evaluate exactly what the situation is, via analysis of all available data sources, but at this time paying special attention to documenting verbal accounts from actual witnesses of “the event.” Such accounts can be of great benefit in subsequent analysis, but their value closely depends on their accuracy and completeness, both of which will rapidly recede with time.
- Step 3. Implement all necessary short-term measures which legally, administratively, or practically have to be taken. From the technical viewpoint, this may include installing additional, simple instrumentation (to help quantify the issue, e.g., structural movement monitoring, flow measurements); increasing the frequency of reading existing instrumentation; site inspection; relocating equipment that is threatened by inundation; or even rapid reduction in reservoir level. These actions help to create a baseline, mitigate the immediate impact, identify if the situation is deteriorating further, and/or help the Project Manager determine the level of imminent danger.
- Step 4. Design and conduct a focused program of new site investigation, the purpose of which will be to establish the exact path of the flow (typically, for a sudden event, it is in a well-defined zone or conduit as opposed to a widely dissipated network of small conduits), its rate and velocity, and the nature of the rock around the conduit. (If the conduit is found to be in a zone surrounded by other clay-filled karstic features which have not, as yet, been “flushed out,” this will represent a severe problem during subsequent remediation and service.) This study will permit a remedial design to be conducted, and its cost estimated. It will also highlight if the flow has the potential to create further distress to overlying or adjacent structures. During this time, the reading instrumentation schedule of Step 3 must be maintained.

The site investigation should comprise the following two tasks, which are complimentary:

- Desk study: review all relevant construction records; historical performance data; instrumentation data; regional, local, and site geology; climatic and seismic records; aerial photographs; personal recollections; construction/quarrying records; and published technical papers. At this stage, the input of personnel originally involved in the project, and contributions from a “local” experienced engineering geologist can be most useful.
- Field study: install investigation holes by the fastest and most economical method to try to physically locate the conduit and the possible existence of “latent” channels. This should be done as far “upstream” in the system as possible. These holes can then be instrumented to provide ongoing data on groundwater levels,

chemistry, temperature and pH, or can be used for various types of geophysical testing, e.g., seismic tomography, or can in fact be used as grout holes in the subsequent remediation. Other types of geophysical testing such as Ground Penetrating Radar, Spontaneous Potential, Electrical Resistivity (Dipole-Dipole or Wenner Schlumberger), and magnetic or gravimetric surveys can be conducted. Dye testing if properly and thoughtfully conducted, can be extremely useful (Bruce and Gillon, 2003).

It may happen that despite the best of efforts and intentions, the exact source or path of the flow cannot quickly be determined with accuracy. Perseverance is essential: the subsequent four steps should not be commenced until closure on Step 4 is satisfactorily achieved.

Step 5. Assuming the situation is to be rectified by grouting, as opposed to merely being monitored and/or managed by other means (e.g., ongoing pumping from the quarry floor), the Project Manager and his advisors can now develop the design for remediation. At this stage, input from specialty contractors and other specialists should be sought, and the technical literature reviewed for case histories of similar nature. It is essential that the design clearly identifies the “measure of success” of the project in terms of, for example, the residual flow rate or piezometric levels at various locations following treatment. It is common to find that few grouting contractors, and even fewer consultants, will have faced such a severe problem before, and unfortunately, most will tend to initially underestimate the difficulty of the remediation. Considerable amounts of time and money have been lost by firstly employing local contractors in haste, who try to “shoe horn” into practice their traditional, simple and conventional methods which are later proved to be wholly inadequate. It is also usually the case that such contractors have been hired on a “cost plus” or “time and materials” basis and so may not be highly motivated to achieve a quick and definitive solution, even if they did possess the technological resources.

Step 6. With the design completed and the basis of the contract approved, the contractor is hired. This should be done on the basis of “Best value” as opposed to “Low bid,” although the two may occasionally be the same. Emphasis should be placed on the experience, expertise, resources (human and mechanical) and work plan of the Contractor, as opposed to his estimated initial price. Engaging the “wrong” contractor will certainly lead to disappointment and dispute over schedule, performance, and cost, and indeed inappropriate construction methods may worsen the situation and make further remediation attempts even more challenging. It is very difficult to accurately estimate the cost of such works at this stage. The Contractor must be regarded as, and must perform as, a technology partner, working in full alliance with the Owner and the Engineer, even

though each party will retain its own prime duties and responsibilities (Carter and Bruce, 2005).

- Step 7. Execute the work. During this phase, all data relating to the contractor's operations (e.g., drilling, water testing, and grouting records, and progress) and impact on the overall structure/bedrock system (e.g., flow characteristics, piezometric levels, structural movements, changes in groundwater chemistry, temperature) must be collected and evaluated in real time by the Project Manager and his team, in "mission control." Only in this responsive, integrated fashion can the effect and effectiveness of the work be revealed progressively, and a sound engineering basis created upon which to instruct changes to the program if required (e.g., need for additional or deeper holes; different grout mixes). Such data are also invaluable in the ongoing process of reevaluating the soundness of the design (Step 5). This step continues until the remediation has been completed and a short-term (e.g., 7 days) confirmation period has successfully elapsed.
- Step 8. A fully comprehensive "as built" report covering all the relevant data from Steps 1 through 7 should be prepared as soon after the remediation as practical. It should contain, as appendices, copies of all meeting minutes, drilling, water testing and grouting logs and drawings, and field instrumentation data and observations. It should include an inventory of all functional piezometers, weirs and other monitoring devices.
- Step 9. Long-term monitoring. The Project Manager must establish a regular schedule for reading all functional instrumentation sources, analyzing their data, and for conducting any relevant revised site or structural inspections. A database must be established, together with a well defined series of protocols to follow if certain instrumentation trigger and threshold levels are reached, or if any significant flow or pressure aberrations should reoccur. These protocols should include details of the responsible person(s) to be notified, and appropriate emergency response plans.

It must be stated that the most effective a grout curtain in karst or other soluble/erodible material will ever be is immediately after its construction. In service, as the full hydraulic gradient is applied to the grout curtain (i.e., the normal operating lake level is restored, or the quarry is pumped out), pockets of ungrouted and/or ungroutable weathered material will be exposed to water pressures which may prove sufficient, over time, to cause such pockets to "blow out." This will occur despite the very best efforts of the design and construction teams. However, there is no predictive capacity as to how severe this increase in residual permeability will be, or how fast it will develop. Clearly, such deterioration will depend fundamentally on the nature of the rock mass (i.e., how much erodible or soluble material remains in place), the applied hydraulic gradient, and the length of time over which it acts.

### 3. **Basic Construction Considerations for Grouted Cut-Offs Used in Emergency Situations**

Definition of the Measure of Success. Pragmatically, a restoration of the conditions status quo ante is a sensible goal. Occasionally, betterment can be achieved, but often it is found not cost effective or even necessary to attempt such relative improvement. In addition to clearly stating what the acceptable post treatment, residual flow should be, other project specific goals, if applicable, should be precisely set, e.g., attaining certain key piezometric levels, structural movement thresholds, longevity of the curtain and so on.

Drilling. Because much will already be known in precise geological terms about the lithology and structure of the rock mass, and because it is generally the goal only to locate and fill major conduits (as opposed to treating microfissures), the drilling should be conducted with the most cost effective method available – provided always that it is compatible with maintaining the security of overlying or adjacent structures. In this regard, the potential of sonic drilling (Bruce and Davis, 2005) is being exploited in major dam remediation. Holes should be drilled at least 150 mm in diameter to permit the later installation of grouting-related pipework or downhole instrumentation. Depending on the rock mass structure, holes may need to be inclined 10 to 15° off vertical to intersect vertical joints. At least two rows of holes are typically necessary in the “flow zone,” for geological and operational reasons, with the holes in each row not spaced more than 3 m apart on centers. It is essential to log carefully the drilling conditions encountered in each hole, so that a simplified geological profile can be established, identifying, as a minimum, the locations and extents of

- Overburden,
- Hard massive rock,
- Fissured rock,
- Very weathered rock,
- Clay infilled solution features, and
- Voids.

Variations of drill flush return (especially total loss conditions, and interconnections between holes) should also be carefully recorded. During the drilling of each hole, the exit point of the flow, if accessible, must be continuously monitored to determine if the conduit has been influenced: flow volume and/or color changes or the presence of drill flush are critical observations. Any interconnections between holes must be accurately recorded (depth, distance and time) since they will be vital to consider in the subsequent injection program. It is essential, of course, that the drilling method (and flush selection) is sympathetic to the structure being grouted. For example, the very vigorous “cleaning” action of air flushed down-the-hole hammer drilling used in a grout curtain around a quarry will not be acceptable when attempting to locate and treat features under an existing embankment dam, or levee.

Grouting Materials. In the cases of fast, large volume flows in very large conduits, conventional “slurry” grouts (High Mobility Grouts: HMG (Chuaqui and Bruce, 2003), even when thoughtfully formulated, will simply be washed away, and can cause an environmental problem downstream of the curtain. Similarly, the potential benefits of highly sophisticated – and expensive – chemical grouts (Bruce et al., 1997) are rarely exploitable since they lack the short-term gelling and strength characteristics to mechanically resist the hydrodynamic forces in the conduit even when the walls of the conduit are relatively clean and competent, which is by no means a common observation. In contrast, the author has experienced success using either Low Mobility Grouts (LMG) (Cadden et al., 2000) in lower head, low velocity conditions, and hot bitumen (together with HMG and LMG) in particularly adverse conditions where the water flow velocity cannot simply be “overcome” by pumping LMG faster as certain paradigms would counsel. Various additives and admixtures including accelerators, antiwashout agents, viscosifiers and even polypropylene fibers are used by the more sophisticated contractors to “tailor” both LMG and HMG grout suites to precise project requirements. In certain conditions, coarse aggregate can be replaced in the void to provide a “skeleton” for later grouts to permeate.

Grout Injection and Sequencing. As noted above, it is common to find all, or most, of the flow channeled into one or a small number of well defined conduits, although very soft, potentially erodible, or fissured rock conditions may still exist in the surrounding bedrock. A basic principle is to allow the water flow to continue *in* these conduits, while treatment continues of the rock mass (through which water is not yet flowing) *around* the conduits. Depending on the nature of the rock mass, this “preemptive” treatment can be conducted by conventional open hole “staging methods,” or by the MPSP (Multiple Packer Sleeved Pipe) system (Bruce and Gallevresi, 1988) – both of which use families of HMG – or by using LMG in upstage, end of casing applications. Again, observation of the flow outlet point is essential at all times, together with an ongoing assessment of any changes to piezometers and other instrument readings. Typically little benefit in terms of flow or pressure reduction is found at this time, even though it is absolutely essential to conduct this work at this juncture (i.e., at a time when the water flow rate in these parts of the final grout curtain is minimal).

The last, and most critical and dramatic phase of the grouting program is to then put the “plug” in the conduit, given that the surrounding rock mass has now been “protected” against the danger of internal erosion when the curtain is functioning. When dealing with flows of 40,000 gpm or more, and head differentials of over 100 feet, cement based grouts – even those of high internal friction and/or cohesion and accelerated hydration – simply cannot be relied upon to resist the situation in the conduit. In such extreme conditions, the use of hot bitumen, in conjunction with the simultaneous and adjacent injection of HMG and/or LMG has proved to be a most reliable solution.

Bitumen has been used in projects around the world for decades, but it is only within the last few years that full engineering value has been extracted from its extraordinary potential. In short, the hot bitumen is directly injected into the conduit flow via very sophisticated pipework. The flow quickly removes the heat from the bitumen (injected at temperatures of 200°C and over) which begins to gel and



congeal. Thus, when pumped at sufficiently high rates, it will begin to overwhelm the flow in the conduit: it does not disaggregate and washout peripherally like HMG or LMG. A simultaneous upstream injection of LMG or HMG causes these cementitious materials to be drawn against the cooling, but still relatively hot bitumen mass leading to a “flash set” of the cement based grouts in the conduit. This multi-material plug continues to form as injection of both types of materials continues. Eventually, the conduit is (temporarily) sealed with the gradually cooling (and shrinking) bitumen plug. At this point, further rapid injection of HMG and LMG is continued upstream of this temporary plug to create the “final” plug which will eventually resist the hydraulic gradient applied to the temporary plug. Failure to conduct sufficient upstream HMG and/or LMG grouting at this time will simply ensure subsequent failure of the operation since the temporary bitumen plug will continue to cool and shrink and so permit the water to exploit the growing gap between conduit boundary and bitumen. The plugging operation must be continued without interruption until completion: unless hot bitumen is pumped continuously down through the down-the-hole pipework at high temperatures, the system will “freeze” prematurely, and the conduit will not be accessed by the bitumen.

The organization and management of the plugging operation is an exercise in detail and logic, and must involve the skills, input, and cooperation of all parties. Clear field leadership is essential, throughout this 24 hours per day operation.

#### **4. Final Observations**

The reader should be cautioned from believing that such projects are anything other than extremely stressful for all the participants. These projects demand the highest levels of technology, administrative engineering and management skills, commitment, and attention to detail. There is an old adage that “you find out about people in adversity.” The development of a sudden and major flow into or under a major engineering structure founded on or in karstic limestone presents serious adversity in various forms to all concerned. It is hoped that this paper will in general provide comfort, confidence, and guidance to those who are faced with such events. In particular, it may form the basis for contingency plans or protocols that could be developed (and hopefully “left on the shelf”!) by managers of major facilities founded in karstic limestone terrain.

#### **5. References**

Bruce, D.A. and F. Gallavresi. (1988). “The MPSP System: A New Method of Grouting Difficult Rock Formations.” ASCE Geotechnical Special Publication No. 14, “*Geotechnical Aspects of Karst Terrains.*” pp. 97-114. Presented at ASCE National Convention, Nashville, TN. May 10-11.

Bruce, D.A. and G. Dugnani. (1996). “Pile Wall Cuts Off Seepage,” *Civil Engineering*, Vol. 66, No. 7, July, pp. 8A-11A.

Bruce, D.A. and J.P. Davis. (2005). "Drilling through Embankments: The State of Practice," USSD 2005 Conference, Salt Lake City, UT, June 6-10, 12 pp.

Bruce, D.A., and M. Gillon. (2003). "Seepage Evaluation and Remediation under Existing Dams" International Commission on Large Dams, 21<sup>st</sup> Congress, Montreal, Canada, June 16-20, 14 p.

Bruce, D.A., J.A. Hamby, and J.F. Henry. (1998). "Tims Ford Dam, Tennessee: Remedial Grouting of Right Rim." Proceedings of the Annual Conference, Dam Safety '98, Association of State Dam Safety Officials, Las Vegas, NV, October 11-14, 13 p.

Bruce, D.A., A. Ressi di Cervia and J. Amos-Venti. (2006). "Seepage Remediation by Positive Cut-Off Walls: A Compendium and Analysis of North American Case Histories," ASDSO Dam Safety, Boston, MA, September 10-14.

Bruce, D.A., R.P. Traylor, and J. Lolcama. (2001). "The Sealing of a Massive Water Flow through Karstic Limestone." *Foundations and Ground Improvement*, Proceedings of a Specialty Conference, American Society of Civil Engineers, Blacksburg, VA, June 9-13, Geotechnical Special Publication No. 113, pp. 160-174.

Bruce, D.A., W.G. Smoak, and C.C. Gause. (1997). "Seepage Control: A Review of Grouts for Existing Dams," Proc. of the Association of State Dam Safety Officials, 14<sup>th</sup> Annual Conference, Pittsburgh, PA, September 7-10, Compact Disc.

Cadden, A.W., D.A. Bruce, and R.P. Traylor. (2000). "The Value of Limited Mobility Grouts in Dam Remediation." Association of State Dam Safety Officials Annual Meeting.

Carter, J. and D.A. Bruce. (2005). "Enhancing the Quality of the Specialty Contractor Procurement Process: Creating an Alliance," Geo<sup>3</sup> GEO Construction Quality Assurance/Quality Control Conference Proceedings, Editors D.A. Bruce and A.W. Cadden, Dallas/Ft. Worth, TX, November 6-9, p 76-87.

Chuaqui, M. and D.A. Bruce. (2003). "Mix Design and Quality Control Procedures for High Mobility Cement Based Grouts." *Grouting and Ground Treatment*, Proceedings of the Third International Conference, Geotechnical Special Publication No. 120, Ed. L.F. Johnsen, D.A. Bruce, and M.J. Byle, American Society of Civil Engineers, pp. 1153-1168.

Dreese, T.L., D.B. Wilson, D.M. Heenan, and J. Cockburn. (2003). "State of the Art in Computer Monitoring and Analysis of Grouting." *Grouting and Ground Treatment*, Proceedings of the Third International Conference, Geotechnical Special Publication No. 120, Ed. L.F. Johnsen, D.A. Bruce, and M.J. Byle, American Society of Civil Engineers, pp. 1440-1453.

Lolcama, J.L., H.A. Cohen, and M.J. Tonkin (1999). "Deep Karst Conduits, Flooding, and Sinkholes: Lessons for the Aggregates Industry." *Hydrogeology and Engineering Geology of Sinkholes and Karst - 1999*, Proceedings of the Seventh Multidisciplinary Conference on Sinkholes and the Engineering and Environmental Impacts of Karst, Harrisburg/Hershey, PA, April 10-14.